



between the tires.

- LOWER FIFTH WHEEL(393.70)  
Check for unsecure mounting to the frame or any missing or damaged parts.  
Check for any visible space between the upper and lower fifth wheel plates.  
Verify that the locking jaws are around